



658450 Sizzix® ScoreBoards™ XL Die - Basket, 3-D by Eileen Hull



1. Die-cut chipboard and apply adhesive to tabs and Basket strips as shown.



2. Fold Basket body piece to fit the contour of the Basket sides. Attach the body to the sides as shown.



3. Adhere the handles to the Basket sides.