




660665 Sizzix® Thinlits™ Die Set - Christmas Tree Fold-a-Long™ Card by Jen Long



1. Fold cardstock in half and place on top of cutting pad.



2. Align the flat edge of the die with the folded edge of the cardstock. Allow the die to slightly hang over the edge of the fold.



3. Fold card as shown.



4. Insert slides into the top and bottom slits of the center tree as shown.