





662449 Sizzix® Thinlits™ Die Set - Card, Gingerbread Fold-a-Long™ by Jen Long



1. Use the single-fold technique to cut the Gingerbread House Card by folding a sheet of paper large enough to accommodate the die.



2. Align the base edge of the die so that it barely hangs over the folded edge of the paper. Place a second Cutting Pad over the top of the paper and dies, and run the "sandwich" through the Sizzix® machine using the appropriate platform configuration.



3. Fold the card base as shown.



4. Slide the top and bottom of the card insert into the slots located in the center of the card base. Embellish as desired.